

Instructions for Hardrock Stoneshield Porous Impregnator SM1000

DESCRIPTION: Hardrock Stoneshield is a clear, penetrating oil and water repellent for use on both interior and exterior surfaces. It will not darken the surface or leave a glossy film. The treated material will retain its natural color and appearance.

COVERAGE: Up to 4000 square feet depending on the surface.

PREPERATION:

1. Take precautions to avoid harm to surrounding areas and people. Protect any surrounding plants, painted surfaces, or non-masonry surfaces with a suitable masking material.
2. Clean the surface to be treated with the appropriate Hardrock cleaner. Be sure to rinse thoroughly and allow to dry completely before apply the impregnator.
3. Always test each surface to be treated before applying impregnator to entire area to ensure desired results. Apply using a brush, roller, cloth or airless sprayer.

SAMPLE TESTING: Before using, always test each surface to be treated in a small inconspicuous area to insure the desired results will be achieved. Consult supplier for further information and precautions, including Material Safety Data Sheets.

HORIZONTAL SURFACES:

1. Apply in a single saturating application with enough material so that the surface stays wet for 2-3 minutes.
2. Highly porous surfaces will require a second application to give the material full protection. If a second application is needed, wait a minimum of 5 minutes before applying. (For best results, wait 1-4 hours before applying.)
3. Buff off any excess impregnator with a wool carpet bonnet.

VERTICAL SURFACES:

1. Apply uniformly from the bottom of the surface to the top with enough material to saturate the surface and create a slight running down below the contact point. Vertical surfaces require a wet-on-wet application.
2. Wait approximately 5 minutes before making the second application.
3. Buff off any excess impregnator with towels or cloth rags.

PROTECT: the treated surface after application. Provide ventilation and fresh air for a minimum of 8 hours on interior applications.

PRECAUTIONS: This product contains heptane and is flammable. Avoid Sparks and electric motors. Do not use near fire or extreme heat. Avoid breathing fumes. Provide cross ventilation and wear NIOSH/MSHA approved respirators. Wear eye protection and protective clothes. Read Material Safety Data Sheet for additional safety and health information.

NOTE:

1. Stoneshield Porous Stone Impregnator will achieve water resistance in 24 hours and oil repellence on most materials in 72 hours.
2. Surface and air temperature should be a minimum of 50°F and a maximum of 90°F during the applications and for a minimum of 4 hours after the application.

FIRST AID INSTRUTIONS:

EYE CONTACT: Flush with water for 15 minutes and get medical attention.

SKIN CONTACT: Wash with soap and water. If irritation persists get medical attention.

INHALATION: Remove to fresh air & provide oxygen if breathing is difficult. Call a physician.

INDESGESTION: Call a physician immediately. Do not induce vomiting. If vomiting occurs, keep head below waist to prevent entry of liquid into lungs.