

Instructions for Hardrock Filler and Adhesive AK3000 (Transparent)

INSTRUCTIONS FOR USE:

To achieve the best results, the contact surfaces must be thoroughly cleaned and dried. Before adding the hardener, the resin may be tinted with coloring paste or iron oxide pigments to match the color of the stone. The resin is then thoroughly mixed with 2%-4% of the white paste hardener (BPO) by weight. At a temperature of 70°F, the mixture stays workable for 4-6 minutes. Higher temperatures shorten the working time and lower temperatures extend the working time. After 20-30 minutes the adhesive is fully cured and you can continue to work with the stone. For indoor use only.

SAMPLE TESTING: Before using, always test each surface to be treated in a small inconspicuous area to insure the desired results will be achieved. Consult supplier for further information and precautions, including Material Safety Data Sheets.

WARNING: Resin Solution, 3, UN 1866.

WARNING: Contains Styrene Monomer, CAS# 100-42-5.

READ THE MATERIAL SAFETY DATA SHEET (MSDS) COMPLETELY BEFORE USE.

Use only in well ventilated areas. When not in use, keep container tightly closed and store in well ventilated areas at normal room temperatures. Never reuse this container or transfer the contents to an unlabeled container. Never cut or weld on this container. Always use proper personal protective equipment while using this material. This product may cause defatting and dryness of the skin resulting in irritation and dermatitis. Always wash thoroughly after handling and before eating, drinking or smoking. Inhalation of vapors may cause upper respiratory discomfort or irritation. Repeated exposure to high concentrations of Styrene may cause damage to the central nervous system, liver and kidneys.

FIRST AID:

Ingestion: Do not induce vomiting. Seek immediate medical attention.

Skin: Wash affected area with soap and water immediately.

Inhalation: Remove victim from exposure to fresh air. If unconscious, administer artificial respiration by qualified individuals as needed and seek immediate medical attention.

Eyes: Flush with water for 15 minutes. Seek immediate medical attention.

In case of emergency, contact Chemtrec at 1-800-424-9300.